



FanBlade

Highest Performance Flying Wing

User Guide

*Fully 3D
Printable*



Wingspan 815mm (32")

Donald Wright

Tested using the
FT Aura 5 LITE AFCS!

Here's an EDF version of a propjet that has had a cult like following for many years. A favorite for experimenting with different power setups, all in the search for highest speeds. This design allows for almost any 70mm EDF fan to be used.

Now you can print your own airframes. Trying different setups and livery schemes is a fun part of the RC hobby. At last, it's not quite as dire when the inevitable mishap happens, simply print another airframe or replacement parts at a fraction of the alternatives. Almost two complete airframes can be fabricated from a single 1kg roll of PLA.

There is now also a lighter weight alternative to typical PLA, A light-weight PLA that has yet to be experimented with by this designer. Hopefully we'll begin to get feedback from the forums and others on this [new product](#). I have some and look forward to it. This EDF version may need typical PLA due to the higher forces in flight – let us know how it works out for you.

Also included in these files is a modular ramp to be used with bungee launches. Using readily available 1/2" PVC and your printed fittings, you have a great alternative to hand launches. Watch the [videos here](#).

Flying wings are unique in that there is little to no fuselage and no empennage. This typically means less drag, lighter wing loading, faster speeds and more maneuverability. However, flying wings suffer from being more sensitive to CG than typical airplanes and they can be hard to successfully maiden. This is where a proven design and setup is very helpful.

A high performance flying wing is a lot of fun and will be the envy of the flying field. Follow this manual for printing and setup and you'll be rewarded with with a plane that will be your "go to" plane regardless of outside conditions. Windy days is where this design eats; add a stabilized RX and fly when everyone else is grounded.

Here are just a few of the innovations applied to this new design;

- Battery strap slots
- Adequate cooling intakes
- Robust double wall fuselage
- Internal wing space for carbon or other reinforcement

- Lightweight (for printing) single layer printing and webbing
- Plenty of space for different powerplants, ESC's and batteries
- Sliding canopy with locking index
- Modular construction
- Servo covers and internal wire routing through the wingtips
- Supplied file for bungee launch hook and launch ramp
- Supplied files for printing your own decals for livery decoration.
- Two different tailcone choices and two nose choices.
- A new "bubble" canopy design. Either print whole or in separate pieces for using different colored filament. Original "windscreen" canopy is included as well.
- Either "Tip Tanks" or "Swept" wingtips choices are supplied.

Let's get to it.

If you have questions or run into trouble, visit the [3D Lab Gang forums](#) and find the dedicated thread for this project.

Bill of Materials (note hyperlinks for suggestions)

1. Your favorite quality PLA printing material. Use a brand that you've trusted before and know the printing parameters for. The supplied "Gcode" files are files that have been set up for Prusa type machines at a size of 200x200x200 and use readily available PLA. You may find that these files work without any modification. If you need to make parameter changes you might want to start with the supplied "factory" files. These are [Simplify 3D](#) files and a great way to understand the "single line" printing processes and how the particular Gcodes were arrived at, and the orientation of parts. Otherwise, the supplied STL files are also supplied as well as "ini" files for basic Cura settings.
2. Motor/EDF – 76.5mm outside diameter x 58mm depth fan housing. This unit was designed around the readily available [PowerFun EDF 70mm, 12 Blade, 6S, 2300KV](#) – this unit can be found in many places, Ebay, Bangood, Aliexpress and Amazon. Other units that you may have might also fit. The fan housing mounts on two wooden bars which will allow for mounting of other housings as well. The tailcones should be easily modified to accommodate variations as well. If

you need a modified tail-cone, write to me and I may be able to modify the existing design for your specific needs.

3. Battery – Test flights were made with a pair (wired in series) of 3S 1550mah and 2200mah batteries, the airframe will balance out with either with careful placement. But this will be dependent on your choice of power systems. The battery bay is gracious and 4,5, and 6S batteries may be accommodated. Higher C ratings helps with battery life, minimizes “puffing” and heat.
4. ESC – Any good quality ESC will work. 80-100 Amp minimum size recommended. The design uses only two servos, so the BEC will not be overworked at all.
5. RX/TX – A programmable radio that allows for “delta” wing configuration is one alternative. A preferred configuration is to use a flight controller that allows on board delta configuration and also offers gyro stabilization. The maiden and flight tests were done using the “Aura” [flight controller](#). This unique design allows for any radio to be used, not necessarily a computer radio. It offers flight stabilization as well as an “assisted” launch mode which is very valuable with a high performance flying wing. Another alternative is to use an RX with stability built in like this [Lemon RX](#).
6. Servos – 2X - [12g Digital Metal Gear Sub-Micro Servo](#) The molded servo recesses are for this size servo – so make sure they are this size or smaller. Digital servos are a better choice when gyro/stabilization is used and metal gears are better for withstanding rough landings.
7. Various bits of wire for pushrods and some [screws](#) for motor mounts etc. Velcro and a battery strap are needed.
8. Decal Sheets - if you wish to use the included graphics. This [Decal Suggestion](#) may also be found on Ebay.
9. Carbon – you’ll need a short piece of carbon tube, $\leq 8\text{mm}$ in diameter x 762mm long. Carbon arrow shafts can be found at sports centers and are typically much stiffer than readily available carbon tubes, they slightly under 8mm, but still work perfectly. If unavailable, hardwood rod may be used at a weight and strength penalty, make a careful choice if wood is used.
10. Servo Extensions – may be needed based on your RX placement and the length of the leads on your choice of servos.

General specifications

Length: 810mm (32in) nose to tailcone

Wingspan: 815mm (32in) – slightly larger with swept tips

Height: 180mm (7in)

Wing area: 15.4 dm²

Wing loading: approx. 81.00 g/dm² using lighter battery pack

Airfoil: semi-symmetrical

Print weight: @616 g

Empty weight AUW (w/o battery): 980g (airframe, esc, servo, fan)

Takeoff weight (2x3s 1550 lipo): 1248g - (2x3s 2200 lipo): 1354g

Flying Wings - [wiki](#)

Flying wings have been experimented with throughout the last century with mild success. Even though the promise of more efficient flight looks great on paper, the reality for full scale aircraft is one of compromise. Often the wing must be increased in thickness to accommodate pilot, engines, etc. and this can eliminate the sought after advantages. But the real problem has always been one of control, effective rudder (yaw) control is a challenge and the designs are pitch sensitive and prone to CG problems.

Fly-by-wire for modern aircraft have overcome many of these control problems as the computer now does the driving by interpreting the pilot's intentions and making the needed changes in control surfaces. Latest tech RC flight controllers offer amazing pilot assistance, overcoming wind, launching, visual range extension and lower landing workload.

Our models don't have to adhere to strict safety and control constraints that full scale aircraft do, our flight envelope is considerably smaller. Modern electronics have also impacted our RC model wings. Aileron and Elevator mixing in our radios and has



resulted in "Delta" wing configurations turning our once dedicated "ailerons" in "elevons".


Yaw control is typically not controlled by a dedicated rudder, the aircraft is turned by a method called "bank and crank". The very same method used by most model fliers of performance aircraft. As one's piloting skill increases we tend to move from the classic high wing trainer aircraft to low wing, higher speed, more maneuverable airframes. Where a rudder is effective for low speed turns on high lift craft with inherent stability, higher speed turns as on jets, warbirds and wings are typically accomplished by rolling the aircraft left or right, the "bank" then pulling back on the stick, the "crank".


Many lightweight RC models such as warbirds, EDFs (jets) and flying wings have no rudder control at all. Flight control is achieved strictly through three surfaces, left and right ailerons and an elevator. In the case of flying wings, only two surfaces, the ailerons. These re-purposed flight control surfaces move in opposite directions for roll and in unison for pitch. The radio, or in some cases, the receiver, mix these two functions in varying degrees based on the pilots input. The right stick (mode 2) works as usual however, up and down for elevator, right and left for aileron.



This model is not for beginning RC pilots. The assumption is that you've successfully maiden and flown typical bank and crank airframes and possibly a foam wing or two. Regardless, the builder must understand the flight regime of flying wings and also have a firm grasp on the necessary programming options of their radio and/or receiver. The latest receivers are inexpensive and have "delta" wing mixing built in as an option, plus, many are now gyro equipped and offer a level of stabilization that was unavailable just a short decade ago. Install one of these in your wing (if not all your planes) and you will be rewarded with rock solid "as if on rails" flying.

The FanBlade has a slightly higher wing loading than similar foam designs or even its brother, the [RazorBlade](#). With this in mind, it requires higher than usual launch speed (airspeed). Bungee, Elevated, or Strong Overarm launch techniques are required. This is a very powerful model and you will find that it will takeoff straight up out of your hand – you might be tempted to launch your FanBlade with this method. I caution against this; being high powered, there is considerable torque and the model *WILL* roll until there is enough airspeed over the control surfaces to counteract this. Many online videos show high powered pushers of this design being let go vertically, the model rolls, corkscrews, arches over and noses into the dirt.











43



Included:

1.STL 3d files

Universal STL files designed for use with desktop FMD 3d printers and slicer software as Simplify3D (recommend) CURA or MatterControl (these STLs are not compatible with Slic3r).

2.Factory files for Simplify3D slicer

With all our setting, this Factory files included all you need, note: we use PRUSA i3 ORIGINAL printers so you may need adjust the basic printing parameters to match your printer or use it as a start point for you, please give a look to Simplify3D

3.Step By Step PDF/VIDEO userguides

Apart from this userguide, please give a look to the Printing Guide with some Tips and Advices for airplane printing (Thin Wall Printing)

4.Gcodes



Basic Gcodes prepared for direct use, so universal as is possible. Should work with i3 style printers, you can try it out, but We can not guarantee that it will work with your printer. 100% works with PRUSA i3 ORIGINAL 3d printers...

5.Prepared settings for CURA and MatterControl slicers

If you dont like Simplify3D for any reason, there is always possibility to use another free slicer you can use our basic setting (setting files) as a start point and edit it as you need.

6.Decal Sheets PDF –

Several pdf files are supplied for you to choose from. You may print these on readily available decal paper using your own inject printer.




Printing

1. Gcodes Preparing

Options A Gcodes:



if your printer is i3 compatible you can directly use [prepared gcodes](#), simply save each to SD card and let 3d printer do his job, HE temperature is set to 230 for best layer bonding, you can edit speed and temperature on your printer LCD only. If Gcodes does not work please proceed to the next options.



Options B Factory files Simplify3D (recommended)

We prepare all you need in this files (basic FFF, parts arranged and so on...)





You can use this our setting as a start point and edit it as you need (adapt it for your printer), print only parts you need and so on... On most 3d printers it should work as it is, but please give a look to the setting and edit it if is different to your printer, we are not liable for damages resulting from the use of our settings. If this does not work please proceed to the next option.



options C Simplify3D manual setting (watch and learn)

Use our [video guide 2](#) for proper setting... this is very good option and you will learn a lot about Simplify3D and become a 3d expert. Of course you spend a lot of time and YouTube pause button will become your friend.

options D CURA or MatterControl



MatterControl and CURA are free and also gives very good results and airframe is still strong enough, slicer setting is very easy.

Please try [find right extrusion multiplier and temperature](#) for good weight and best layer bonding, give a look to parts weight list for proper multiplier setting.

You can also use our [predefined](#) CURA or MC slicer setting file included in package (always adapt it for your printer, change build volume, filament diameter and so on... depends on your printer!!!):

[CURA_wing_fuse.ini](#) (wing and fuselage and so on... parts)

[CURA_ailer_elev.ini](#) (only ailerons, elevator and rudder parts)


[CURA_thick.ini](#) (motor mount, battery holder, spinner)

OR

[MC_wing_fuse.slice](#) (wing and fuselage and so on... parts)


[MC_ailer_elev.slice](#) (only ailerons, elevator and rudder parts)

[MC_thick.slice](#) (motor mount, battery holder, spinner)




AND... please give a look at these VideoGuides;

[Video Cura](#) slicer setting



[Video Matter Control](#) slicer setting



2. Print it

Save generated Gcodes and insert SD card to your printer, prepare your printer and start printing, we prefer to use SD than direct connection via USB Note: ABS filament is not suitable or this...

Scaling the model will lead to unusable result!

[video guide about printing](#)

You will need: PLA filament - good quality and strong PLA (we need good layer bonding)

Strong hair spray (or your favorite adhesive bed surface)

Razor blade

AND... please give a look to VideoGuides: [Video](#) printing guide (similar to this 3D LabPrint Spitfire)

Basic Tips and Advice

Please Experiment with your [extrusion multiplier](#)...

Also [HotEnd temperature](#) is very important for strong result, please try increase temperature to find the best value ([200 up to 260 celsius](#))

Turn [OFF cooling](#) fan for better layer adhesion ([Hot End fan ON of course](#)) we don't need it for our thin wall printing...

We tried a lot of filaments and so far PLA is still the best for our models (2016). You can try also PETG and PC-max from Polymaker is very promising filament.

HEATED BED is very recommended, 60-70celsius (print without warping ends) (but please read personal note below)

Looks like any standard quality PLA is OK for our planes, BUT it always depends on combination PLA vs. Extruder vs. HotEnd.

We find that some color of filament has lower layer adhesion, always check if you are printing in a solid color.

Nowadays there is lot of 3dprinters on the market, most of them are OK for printing our aircraft (specific thin wall printing...) sufficient volume, heated bed, 0.4mm nozzle.

3D LabPrint Printing Guide

More on Printing Parts

Most all of this project is printed using the "single" line printing technique as outlined by [3D LabPrint](#). Essentially there is "no infill" selected, and only 1 layer on outside, 0 on top or bottom on most parts. Simplify3D (and other software may) allow for the creation of special options, such as 2 outside layers up to 1mm then only 1 thereafter. This allows for a little thicker edge where parts are glued together.

You will also find that printing the ailerons, horns down, with 6 bottom layers creates a solid control horn.

Layer height – 0.2mm for most parts

Nozzle Diameter - 0.4 mm

Time Lapsed Videos

Watch these videos on printing suggestions on the typical parts. You can learn a lot about orientation, etc.

NOTE; These are videos of the [RazorBlade](#) being printed. Many parts of the FanBlade are similar except Fuse D and Wing B1 most notably.

[Ailerons](#) [Canopy](#) [Fins](#) [Fuse A](#) [Fuse B](#) [Fuse D](#) [Fuse E](#) [Launch Hook](#) [Motor Mount](#) [Wing](#)
[Section SBA3](#) [Wing Section SBB3](#)

[FanBlade Maiden Flights and Launch Setup](#)

Personal Printing Note From the RazorBlade Designer:

I've found that keeping a high bed temp (60c+) with thin parts causes radial shrinkage (5mm-20mm above the bed) during longer prints. My best printing now uses a low heat (35C) bed temp. I print on 3M Blue Original Painter's tape which I squeegee down on glass with a credit card. A slower first layer speed (60%) at the proper height, gives a great bond for the duration of the print. Make sure the temperature for your particular brand of PLA bonds each layer well. This may change slightly with different colors within the same brand. Accuracy with our prints depends on a tight, well setup machine, quality manufactured filament (diameter tolerance) and lastly accurate temperature management. Insulation on the hot end (such as a silicone cover or cotton padding) (see time lapse videos) helps the controller keep a rock steady temperature. Keeping a steady temperature minimizes visual print anomalies.

Additional note – I've been experimenting with [PEI bed sheets](#) from various 3D print suppliers and have had good success. If anything, large flat base prints, are almost impossible to remove – so it seems to be good for our single line printing, especially if you use an attached skirt of several lines on small parts. You will see in the factory file, "Wing A4" I have moved the skirt to touch the part and increased the lines. You can use this method to counteract shrinkage lift on large parts too.

Note; Most FanBlade parts are printed with "2 Layers Bottom" as opposed to "0 Layers Bottom" - This offers a bit more gluing strength and a natural diaphragm for added integrity on this high speed model.

Note; Since the above notes on "bed adhesion" was made, I've found and experimented with many of the new "bed adhesive liquids such as [Layerneer](#), [Nano Polymer Adhesive](#), [gluestick](#) and others. The technology is now such that bed adhesion problems are mostly in the past – so much so that modern adhesive compounds with actually break the bed glass if one isn't careful – it's happened to me a few times. Prusa has their own proprietary bed materials which are very good, but it also is worthwhile to experiment. It takes a broad knowledge of bed adhesion when you consider all the modern filaments available – many of which are new to the market.

Note; due to the development of better bed adhesion alternatives, The FanBlade wing sections, A1 and B1 have had their "relief slots" removed as compared to the RazorBlade, if you've also printed that airframe. Better bed adhesion now makes for perfect prints with little to no shrinkage.

3. Assembling printed parts




- Note: Assembly suggestion – I've found this [glue](#) to be excellent and a much cheaper alternative to hobby shop comparables. Works with accelerator, safe for PLA, bonds almost instantly with a bit of pressure, safe for some foams. Otherwise, you can use your favorite hobby shop medium CA, I like to use the foam safe due to lower fumes and its much more versatile.
- Note; as many of you long time printers have now discovered, using CA accelerator will eventually discolor PLA months down the road. The glue noted above will grab (without kicker) and hold parts especially if pressure is applied and held with blue tape, etc.
- Note: Assembly suggestion – The use of true 3M Brand blue [painter's tape](#) is recommended for many assembly processes. As mentioned above, I also use it for bed adhesion and it works perfectly 99.9% of the time. When assembling portions of wing, I simply cut squares of the tape (I buy the 1.88" width) and use


two or three squares as temporary “hinges” between two parts. I carefully line up the parts and squeegee the tape down using an old credit card. Then I open the parts like a book and carefully apply the glue, close the book, double check alignment and apply moderate pressure for a few seconds. Peel the tape off before the glue kick completely to prevent leaving a stuck blue blemish. Super simple and effective.


- I also use a full sheet of 180-220 grit sandpaper laid upon a flat surface to “dress” the mating surfaces of parts before assembly. This ensures there are no printing “artifacts” that might prevent good joint closures. This is important!

Fuselage Assembly -

From the pictures below, you may use thin plywood pieces to insert between sections, this makes assembly much easier and stronger. Always test assemble first before applying glue!







A note on fastening the Bungee Launch hook

The hook pad (if used) is fastened to the underside of the fuselage. The back edge of the pad is aligned with the joint between the "Fuse B" and "Fuse C" sections. You will find that the shape of the pad fits perfectly the fuselage at that particular spot. This placement gives the best balance between forward speed and vertical gain during the launch. See cover picture.

Wings assembly

First assemble the wing "A" parts, A1, A2, A3 and A4 together.

Now assemble wing "B" parts, B2, B3 and B4 – make sure of careful alignment.



Next, assemble "B1 and "B2" together with the fin between. Careful pre-alignment and trimming may be necessary before committing to gluing.

Test your 8mm carbon tube in the recesses of the leading and trailing edges of the wing. Again, make sure the tube fits easily between the halves, if so, then proceed. If not, wrap a bit of fine sandpaper around the tube and sand out the recess of obstructions.

1. Again, using the noted "tape hinge" technique described above, assemble the "A" Leading Edge to the "B" trailing edge. (sand mating surfaces flat beforehand)
2. Same technique, assemble your choice of wing tip "A1" and "B1" to the end of the wing.
3. Aileron assembly. Straightforward, this is best accomplished on a flat surface, you can use a cooking parchment paper under to prevent the parts for sticking to the bench.
4. Hinge installation – it's easier to install the ailerons at this time. Use your favorite [CA Hinges](#) for fastening ailerons to back of wings. Be sure to "flex" the ailerons downward to get the correct hinge gap before applying glue. I use regular thin CA to make sure it wicks into the pocket. Don't apply kicker if possible and let harden naturally. "kicking" the CA flashes the CA and results in a crusty hinge that does not flex as well. If you find the printed slots are slightly oversize, then back up your hinges with small cut sections of additional hinge. Important!
5. Cut your 8mm carbon tube to 750mm (29-1/2") and center it though the fuselage hole. Slide the wings into place and glue securely. Use tape and careful

methods to pull wings tight to the fuselage. Arrow shaft or hardwood is an alternative. If hardwood, definitely reinforce wing with tape as shown step #7.

6. This step deleted.
7. Wing reinforcement – Depending on how hard you intend to fly your RazorBlade, you might want to consider adding reinforcement. This can be accomplished several ways. 19Mm wide strapping tape (fiberglass stranded) can be applied above and below on the center wing spar. Also, you can use fiberglass tape such as used on drywall joints on the underside at the wing roots, this will help immensely with 'high-G' turns. (See Pictures)




8. Hatch – Glue halves together and test fit on fuse. The hatch should slide into place and "clip" over the latch on the last few millimeters. The FanBlade has options for the canopy. The traditional "windscreen" and the newer bubble canopy. The bubble canopy comes in two versions, "complete" or "separate". The complete version is similar to the original where you will have to paint the "glass" area by hand. The separate version has the bubble section separate where you can print in clear or any color you desire.


Airframe is now complete!

Final assembly -

1. Bind your RX on the bench, connect the ESC and EDF and determine correct motor direction. Mark the wires and disconnect. Due to the depth of fuselage you will need to feed the ESC wires through the motor mount, connect the motor and pull the wire back into the fuselage. The suggested motor/ESC combination has long enough power wires to do this.
2. The fan housing mounts should be made out of 8mm x 8mm x 80mm clear fine hardwood such as birch, or maple. Select carefully and sand by hand to get these mounts to slide into the rear of Fuse D openings. Don't drive them in, they need to be snug, but not tight enough to damage the printed part. Just a dab/dot of flexible glue on the outside edge is all that's needed – you might need to remove it one day for repairs.




3. Attach the fan housing to the mounts using 3mm bolts and locknuts as shown. Be sure to carefully drill the hardwood mounts for this purpose. The fan housing should be tight up against the Fuse D intake ring.
4. The fan "midhousing" now slides over the fan assembly and aligns with the help of small wooden keys like the ones used on the fuselage assembly. Don't glue. You will find that the back/bottom edges of the wood mounting blocks need to be beveled a bit to clear. Use small #2 button head wood screws on either side of the midhousing into your premarked and drilled holes in the mounting blocks. The tail-cone may either be glue on now or preglued after fitment confirmation. Note; depending on bolts/screws used, you may need to remove some material from the midhousing to be able to slide into place.



5. Mounting the RX/flight controller and ESC is much easier if you attach them both to a small strip of light-weight plywood, then slide them into the fuselage recess and fasten on the front end with small screws.
6. Apply a strip of Velcro onto the battery area.
7. Feed a battery strap through the fuselage slot.
8. Attach the servo extensions to the servos, if needed. I use a short piece of heat shrink around the connectors to ensure they stay firmly together. Feed through the servo lead tunnel and attach to the RX.
9. Ensure that you are using an adequate servo arm (the shortest possible) and that it is firmly attached. Fit the servo into the pocket and use a small application of medium CA on either side to hold in place. Just a dab is enough, we want to be able to nibble it out if we need to replace a servo.

10. Fit the servo covers into place and use a very small dab of CA to hold them there.
11. Bend your servo push-rods as shown. You may have to use a pin vise and drill bit to clean out the aileron holes to the perfect size. Extra care taken here will ensure a control surface without slop and precision in the air. I don't like "Z" bends – they are hard to make accurately and they "enlarge" the hole while trying to get them into place. My preferred method is to make a hard right angle bend where needed and use another piece of smaller diameter wire as a "keeper." See picture – once you use this method you'll appreciate how easy it is and especially for installation and removal.



Also notice the extra "V" bend in the pushrod, this is a tried and true method for accurately adjusting the length during the installation.

12. Consider applying a strip of sandpaper on both sides of the fuselage where you would naturally grip the plane for hand launching.

Setup

1. Configure your RX or TX for "delta" wing configuration and verify correct movement of the surfaces with the intended stick movements. If your RX is stabilized, then you also need to ensure the correct surface movements vis-a-vis air frame movements. Hopefully this is not your first gyro setup, but if it is, be absolutely positive that you understand and have the parameters set up correctly. A stabilized plane with incorrect surface setups will not fly, a hand launch stabilized plane will crash immediately! (I've seen this happen more than once – not me of course . . . a friend. ;-).
2. note deleted
3. Control surface throws – High Rate – 5/8" (16mm) up and down, 50% Expo. Low Rate – 1/2" up and down (12mm), 60% Expo. (Measured at aileron tip next to fin) Yes, that's a lot – but during a hand launch, you want full control

movements for those initial seconds, after that the expo will tame down the movements for smooth flight. You may find launching on high rates and switching to low rates after settling in will be beneficial.

4. Center of Gravity (CoG) – is very important on flying wings as there is no tail to help counteract an imbalanced airframe. There is a molded “bump” on the underside of the wing, this is the recommended CoG, balance the airframe on your fingertips. Battery movement and a spot of lead might be necessary to get the proper CoG. The design will/should balance with a range of 6S battery sizes from 1550mah though to 6S 2200mah Lipo battery. Smaller batteries in the forward position and larger ones pushed back of course. Try to adjust your components while building to keep from having to add any extra weight. Our initial flights used 6S 1550 75C batteries. Make sure you have C rated batteries that can power high amp fan.
5. Neutral Control Surface Setup – The FanBlade airfoil is designed with a little reflex, this means that a neutral setup on the ailerons is EVEN with the wing surface (part B4). Also, high power EDF units make torque, you *may* want to dial in a little right aileron bias to counteract for fan torque. (SB aileron up 1mm, port aileron down 1mm). Most likely you will be trimming this in once the bird is flying anyway. (with this in mind, confirm your fan direction!)

Livery

I like to paint my planes with a coat of [Minwax Polycrylic](#) or [Deluxe Eze-Kote](#) a modified waterbased urethane product (WPU) that goes on thin, dries quickly without brush marks, sands easy if needed. Being a urethane, it is essentially an adhesive, which adds a bit of strength to our printed planes by “filling” in the record grooves of the printing process. This material is super, try it, you’ll find many uses for it!

A coat of clear and then use any rattle can paint for graphics as wanted. Or use the supplied PDF, water slide decals, and your inkjet printer to make perfect professional looking graphics. Another coat of clear seals the decal edges once applied. Have fun here and personalize your FanBlade or a fleet of them.

Flying

For a successful maiden flight you need several things in your favor.

1. Correctly setup airframe

2. Confirmed CoG
3. Confirmed Neutral Flight control surfaces, moving in the right direction. Check gyro response and it's directions too!
4. Fully charged battery
5. Wind in your face
6. Proper Launch Technique

The first four have been covered and are obvious. Wind in your face indicates that you're going to launch "into the wind" this increases our "airspeed" and decreases our "ground speed." Increased airspeed gives us lift and surface control, decreased ground speed minimizes damage if the worst happens. The FanBlade is not afraid of wind, so you don't be either. It will penetrate and cut through when other planes are left in the hangar.

Proper Launch Technique – is just that. You can't limp wrist this bird and expect to have success. Attention to a proper launch is critical EVERY TIME!

1. Radio on a neck strap lanyard, that way you can one hand the throttle.
2. Feet together
3. Arm outstretched overhead
4. Bird balanced between thumb and forefinger. A good solid grip (you applied your sandpaper, right?)
5. Nose pointed upward 30 degrees from horizontal. (this is important, find out what 30 degrees looks like) WINGS LEVEL!
6. Now, in one fluid motion, like throwing a baseball, step forward and chuck the bird hard, upward into that 30 degree incline, while advancing the throttle to full.
7. A proper launch into the wind will have the bird arc over to level flight while you're putting your hand on the right stick ready to pull elevator. If you've done it right, you don't lose altitude. (a stabilized RX is great for hand launches)

I've seen so many hand launch birds go in on launch due to not paying attention or developing a good launch technique. A weak chuck and the plane will stall and pancake into the ground. Arm not extended and you hit your own head or hat with the left wing. Wings not level, she veers off left or right, stall and crash. Advancing throttle

too late or not enough. Getting freaked out and over-correcting, the plane flops around like a fish, stalls and goes in. This is not you!

A hand launched bird has the benefits of being lightweight with better aerodynamics due to no landing gear. These smaller birds are cheap and most of all, fun. That's what its all about right?

Alternate Launch Technique – The Launch Ramp

If you've done a lot of hand launches in your experience as an RC flier, you know that eventually one will go wrong. Consider bungee and ramp launches as an alternative. It allows a pilot to focus on the sticks and watch the plane from the get-go. Most experimenters using high power setups use a bungee launch to get their bird up to initial speed. Try it, you won't be disappointed. Here's notes on using the include files to make your own ramp launch system.

A successful launch system has several working parts that need attention. Your ready-to-fly FanBlade should weight around 2.8lbs. A good rule of thumb is to have about 4-5 times the takeoff weight in bungee pull. The test flights were made with 12lbs of pull. But that's not the entire equation, you also need length to dampen the pull, otherwise we'd have too hot of a cat launch which will result in damage. We need about 60 feet of 5/16 surgical tubing and we double that in two for 30 working feet. Quality surgical rubber tubing will easily elongate 300%. So we are going to stretch that tubing about 80-90 feet – 25/30 paces. Use a fish scale if you have one to get the initial pull verified.

Attached to your surgical tubing you will need 50 feet of strong nylon twine, the kind brick masons use can be found at Lowes and other hardware stores. The line allows the launched plane to climb a distance before coming off the line – don't launch on tubing alone.

What you'll need:

- [Line](#) and [surgical tubing](#) as described above.
- A few 1" [key rings](#) available at any hardware store.
- A 3/8" diameter timber spike (nail) 12" long. For the Ramp Launch Block end.
- A suitable stake, tent stake or dog leash yard screw – For the rubber end.
- 20 feet of 1/2" PVC, Schedule 40 will work, 80 is a bit better.
- 8pcs 1/2" PVC Tees
- PVC glue

Print out the parts.

- 1pc Ramp Clip
- 16pcs Ramp End Caps

- 1pc Ramp Release Block
- 1pc Ramp Release Handle

Instructions;

Cut the pipe to length;

- 2pcs 60"
- 2pcs 24"
- 2pcs 12"
- 2pcs 6"

Glue the tees onto each end of the shorter tubes – each end must be 90 degrees out from each other. Glue 8 Ramp End Caps onto four tee tube ends flush by laying on workbench. After alignment, pushing the clips into place with a vice helps. Glue the other 8 Ramp end Caps onto the opposite end at a 45 degree angle. See pictures.

Glue the Ramp Clip solidly onto the Ramp Release Block, with the opening facing downward.

Assemble your ramp by clipping the 45 degree ends about 12" from both ends of the 60" tubes and then clip the bottom cross tubes into place – the object is to leave about 3-1/2" to 4-1/2" between the launch rails. Of course you'll see how to adjust this to fit not only the FanBlade, but other planes as well. This design leaves smooth and uninterrupted launch rails. A properly assembled launch ramp will not hinder the plane in any way.

See the pictures for proper assembly.



Clip the launch block to the front cross rail and pin to the ground with your spike. Stretch out your line and pin the other end to the ground securely. Be extra careful with spiking the rubber end of the assembly, you do not want it coming loose and rocketing toward you during the loading!

Use a short piece of line tied to the release handle. Stretch out the line and clip the keyring into the Release Block using the Release Handle. See pictures. There will be a short piece of line from the locked in keyring to another keyring which hooks to the underside of the plane.

Launching – With all ready and double checked. With a smooth motion use your foot or a helper to pull the release handle. Once the plane is off the ramp, apply smooth throttle and steer the plane straight out, up and off the end of the line. Do not apply any throttle until the plane has been released, doing so will cause the line to fall from the hook early, the line will shoot away and the plane will simply nose off the ramp into the ground.

Innovation

Sure, there are a lot of flying wings out there, the simplest type of flying there is. But there are not many 3D Printed flying wings yet. This design explores the state of the art while having fun doing it. The generous hatch area, double wall fuselage, bungee launch capability all add to a great experience and fun RC flying with your buddies.

All the best, Don – and the 3DLabGANG

P.S. I'm also a writer. If you are a reader of suspense novels you will enjoy my book, "Found Money." [Available on Amazon](#)

An elegant and simple design is the result of an investment of sweat equity from the designer. Please honor that investment and keep these files private. Thank you.